Nintendo
ENTERTAINMENT SYSTEM™

M82 GAME SELECTABLE WORKING PRODUCT DISPLAY

ASSEMBLY AND INSTALLATION INSTRUCTIONS

CONNECTING M82 TO MONITOR

If the product display is to have a TV or monitor placed on top of it, make sure the TV is not too large to safely fit.

For the best possible picture quality, use a TV/monitor with direct audio/video inputs and hook it up following Drawing A. Remember to switch the TV to direct audio/video input.



CONNECTING M82 TO TV

If no TV/monitor is available with direct audio/video input, then switch the TV to Channel 3 and use the VHF cable provided. Hook it up following Drawing B.



NOTE: On some TV sets with screw-on connections, it may be necessary to use a UHF/VHF Matching Transformer. (Not Provided)

ALSO NOTE: If Channel 3 is broadcasting in your area, then set the switch on back of the product display to Channel 4.

C



OPERATION

CAUTION : Always turn power switch to Off position before plugging in or unplugging the M82.

1. Plug the M82 into a standard 110 volt, 60 cycle outlet.

2. Turn the power switch on.

3. Choose a game by using the game select button.

4. Start the game selected using either the left controller or the gun (depending on game).

NOTE: Different game play limits may be selected by turning the game time limit switch on the back panel of the M82. (Factory setting is 3 min.)

CAUTION: Do not attempt to open the M82 without first contacting an authorized Nintendo merchandiser.